The Wall Whale Instructions and Tips and Tricks



The Old Way

With an ordinary brush, you use two hands to make a series of short strokes, one hand to hold the brush against the pool surface and the other to push the brush down.

This method requires multiple passes over the same area and is strenuous because there is no way to hold the brush firmly against the pool surface.

chatter




The New Way

With the Wall Whale, the key is to start at the waterline and keep it moving.

Position the brush so the bristles are at the top of the waterline, reach as high on the pole as possible, and make one fluid stroke to the bottom of the pool. As long as the Wall Whale is moving, it will grip the walls (or bottom) of the pool.

A new brush will have "chatter" which causes it to bounce slightly for the first 10-15 strokes. Thereafter it will move smoothly.




Adjustable Settings

The Wall Whale has a bracket to adjust the amount of force it creates against the wall.


For normal brushing, the medium setting is best. If it requires too much effort to push, move the adjustor bracket to a lower setting.

When you are brushing steps or the floor of the pool, you have gravity on your side and the force created by the Wall Whale can make it difficult to push. Move the adjustor bracket to the lowest setting or remove it completely for this part of the job.



To remove the adjustor bracket:

- 1 Press your thumb against one of the **support** rails. Do not try to squeeze both sides of the adjustor bracket, it will be too hard to remove or replace.
- 2 Squeeze the opposite side of the adjustor bracket.



3 - Tilt and lift - the bracket will easily pop out of position. To replace the bracket, position one pin in the hole and repeat the process, pushing down to get the opposite pin into place.